

No	Mode	Mode Group
1	CW	CW
2	PHONE	PHONE
3	IMAGE	IMAGE
4	DATA	DATA
5	AM	PHONE
6	C4FM	PHONE
7	DIGITALVOICE	PHONE
8	DSTAR	PHONE
9	FM	PHONE
10	SSB	PHONE
11	ATV	IMAGE
12	FAX	IMAGE
13	SSTV	IMAGE
14	AMTOR	DATA
15	ARDOP	DATA
16	CHIP	DATA
17	CLOVER	DATA
18	CONTESTI	DATA
19	DOMINO	DATA
20	FSK31	DATA
21	FSK441	DATA
22	FT4	DATA
23	FT8	DATA
24	GTOR	DATA
25	HELL	DATA
26	HFSK	DATA
27	ISCAT	DATA
28	JT4	DATA
29	JT65	DATA
30	JT6M	DATA
31	JT9	DATA
32	MFSK16	DATA
33	MFSK8	DATA
34	MINIRTTY	DATA
35	MSK144	DATA
36	MT63	DATA
37	OLIVIA	DATA
38	OPERA	DATA
39	PACKET	DATA
40	PACTOR	DATA
41	PAX	DATA
42	PSK10	DATA
43	PSK125	DATA
44	PSK2K	DATA
45	PSK31	DATA
46	PSK63	DATA
47	PSK63F	DATA
48	PSKAM	DATA
49	PSKFEC31	DATA
50	Q15	DATA
51	QRA64	DATA
52	ROS	DATA
53	RTTY	DATA
54	RTTYM	DATA
55	T10	DATA
56	THOR	DATA
57	THROB	DATA
58	VOI	DATA
59	WINMOR	DATA
60	WSPR	DATA